



## CDHD Servo System Wiring Single-Phase



\* To be supplied by customer

Refer to EMI Suppression in the user manual


**CDHD Servo System Wiring**  
**Single-Phase**



\* To be supplied by customer

Refer to EMI Suppression in the user manual


**CDHD Servo System Wiring**  
**Three-Phase**



\* To be supplied by customer

Refer to EMI Suppression in the user manual


**CDHD Servo System Wiring**  
**Three-Phase**



\* To be supplied by customer


Refer to EMI Suppression in the user manual

## CDHD Servo System Wiring Three-Phase




\* Internal 33Ω 300W. For higher power, external regen resistor is required; refer to the user manual  
Refer to EMI Suppression in the user manual

## CDHD Servo System Wiring Three-Phase



**CDHD Servo System Wiring**  
**Three-Phase**



\* Internal 12Ω 300W. For higher power, external regen resistor is required; refer to the user manual

Refer to EMI Suppression in the user manual